

Mixars Primo Jogwheel Touch Sensitivity Calibration

- 1) Press and hold NOISE + FILTER then power on to enter Audio mode switching



- 2) Don't touch Jogwheels during the calibration!



- 3) Press SHIFT to save the parameters.



- 4) Calibration is done!